

# **PUC-005**



## **IMPORTANT SAFETY INSTRUCTIONS**

- . Review all instructions before assembling the cart.
- . Improper assembly can cause personal injury and/or property damage.
- . Do not overload cart. See specifications for load capacity (distributed evenly).
- . Do not step into or on the cart, or use it as a toy.

opeomedicins	
Model number	PUC-005
Load capacity	550 lbs. (250 kg)
Upper platform size (LxW)	95.5*65*23.5cm
Upper platform height from floor	74.5cm
Caster size (OD x W)	5inch
Overall dimensions (LxWxH)	118*65*87cm
Net weight, approx.	21.3kgs(47lbs)
Shipping weight, approx.	22.8kgs(50.3lbs)

### **Specifications**

## Assembly

Tools required: cross-point screwdriver, and rubber or wood mallet.

Use the mallet to tap down the parts to ensure they are seated properly before fastening them with screws.

- 1. Turn upper platform upright(#2) and install handle (#1).
- 2. Turn upper platform assembly upside down, and install legs (two left and two right, #4 and #5)
- 3. Install lower platform (#3) and casters (#6,#7). Tighten all screws and hex nuts. (#8, #9, #10)

Index No.	Description	Qty.
1	Handle	1
2	Upper Platform	1
3	Lower Platform	1
4	Left Leg	2
5	Right Leg	2
6	Universal Caster Assembly Ø5 in	2
7	Fixed Caster Assembly Ø5 in	2
8	Tapping Screw M6x30mm	12
9	Screw Bolt M8x42mm	16
10	Hex Nut M8	16
11	Wrench	1

#### Parts Breakdown

